


40F-5



No.	parts description	number	No.	parts description	number
1	BOLT M5X16	3	26	FLY WHEEL	1
2	AIR FILTER ASSEMBLY	1	27	PLAIN CUSHION ϕ 8	2
2-1	AIR FILTER COVER	1	28	NUT M8X1.25	1
2-2	AIR FILTER	1	29	EVEN FILLING PIECE	2
2-3	SPOONGE	1	30	CLUTCH	1
2-4	AIR FILTER MOTHER BOARD	1	31	PROFILE FILLING PIECE ϕ 10	2
3	BOLT M5X55	2	32	CLUTCH SET BOLT	2
4	SHOOT THE PAD ϕ 5	10	33	LEFT COVER	1
5	CARBURETOR ASSY	1	34	BOLT M5X25	4
6	CARBURETOR PAPER PAD	1	35	RIGHT BOX BODY	1
7	BOLT M5X25	2	36	OIL SEAL ϕ 12X ϕ 22X7	1
8	INTER PIPE	1	37	STARTS THE DRIVING PLATE	1
9	INTER PIPE PAPER PAD	1	38	NUT M8X1.25	1
10	SPARK PLUG	1	39	ALUMINUM FILLING PIECE	1
11	CYLINDER BLOCK	1	40	HAND PULLING STARTER	1
12	CYLINDER BLOCK PAPER PAD	1	41	BOLT M5X20	7
13	PISTON RING	2	42	HIGH-PRESSURED PACKAGE ASS'Y	1
14	PISTON	1	43	OIL POT CLAMP	1
15	PISTON PIN ELASTIC RING	2	44	OIL POT ASS'Y	1
16	PISTON PIN	1	45	BOLT M5X20	2
17	ROLLER BEARING	1	46	OIL POT PROTECTION FRAME	1
18	BENT AXES ASS'Y	1	47	CYLINDER BODY SHELL	1
19	WOODRUFFKEY	1	48	CYLINDER COVER	1
20	BEARING 6202	2	49	BOLT M5X20	4
21	LOCATING PIN	4	50	MUFFLER PAPER PAD	1
22	GATHERS THE BOX PAPER PAD	1	51	MUFFLER ASS'Y	1
23	LEFT BOX BODY	1	52	BOLT M5X12	2
24	OIL SEAL ϕ 15X ϕ 30X7	1	53	BOLT M6X55	2
25	BOLT M5X30	4	54	MUFFLER COVER	1